

Replace the iPhone 4 Battery

07.20.2015

| iPhone 4, iOS 4 - iOS 7 |

Overview

The iPhone 4 battery will continue to hold less charge over time until you need to replace it. You can easily hire a company to replace it or you can do it yourself. Here we explain how to do it yourself.

Step 1 - Buy a replacement battery from an online store such as eBay. Be sure to get the model that matches your phone.



Image courtesy of: eBay.com

Step 2 - Unscrew the two screws on the bottom of the iPhone. Make sure your iPhone is turned off.



Image courtesy of: [ifixit.com](https://www.ifixit.com)

Step 3 - Slide the back cover off.



Image courtesy of: ifixit.com

Step 4 - Unscrew the screws connecting the battery to the iPhone.



Image courtesy of: macworld.com

Step 5 - Remove the old battery by pulling on the plastic tab. Replace it with the new battery.



Image courtesy of: macworld.com

Step 6 - Carefully reassemble iPhone.



Image courtesy of: ifixit.com

Additional Resources

- [How to replace iPhone battery - Video](#)
- [Replacing iPhone battery - Article](#)
- [Replacing iPhone battery - Article 2](#)
- [Replacing iPhone battery - Article with video](#)

References

- [Macworld](#)
- [VIDEO](#)
- [VIDEO 2](#)
- [EveryMac](#)
- [iFixit](#)

Get social with us!



[/iphonestoreww](#)



[@iphonestoreww](#)



[iphonestore](#)

Click to Contact Us:

[**iPhoneStore.com**](#)

[Email us -](#)

[support@iphonestore.com](#)

© 2015 iPhoneStore.com All Rights Reserved